











SOLEN PURE SPEAKER KIT - ASSEMBLY INSTRUCTIONS (2/2) 4. DAMPING MATERIAL \*\*THIS STEP HAS ALREADY BEEN DONE IF YOU BOUGHT THE ASSEMBLED CABINET\*\* APPLY THE DAMPING PAD INSIDE THE ENCLOSURE AS SHOWN ON THE "DAMPING MATERIAL" PAGE. YOU CAN USE A ROLLER TO APPLY PRESSURE TO MAKE SURE IT IS GLUED CORRECTLY. IT IS RECOMMENDED TO USE STAPLES TO MAKE SURE THE PADS DON'T COME OFF. INSTALL THE RECYCLED FELT (FLEX-XEL-S-125) IN THE CABINET AS SHOWN ON THE "DAMPING MATERIAL" PAGE. IT IS RECOMMENDED TO USE STAPLES TO MAKE SURE IT DOESN'T MOVE AROUND. 5. INSTALLING THE PARTS CONNECT ALL THE CABLES ON THEIR RESPECTIVE TERMINALS ON THE CROSSOVER BOARD: SCREW THE CROSSOVER BOARD INSIDE ON THE BOTTOM OF THE CABINET (USING THE 6X3/4). DON'T OVERTIGHTEN THFM. 3. CONNECT THE TWEETER AND SCREW IT IN PLACE (USING THE OXSOCKET8X1); USE A TIE-WRAP TO FIX THE TWEETER CABLE ON THE PORT SO THAT IT DOESN'T MOVE AROUND (THIS STEP IS OPTIONNAL, BUT RECOMMENDED); CONNECT THE WOOFER AND SCREW IT IN PLACE (USING THE OXSOCKET8X1); CONNECT THE TERMINAL CONNECTORS AND SCREW IT IN PLACE (USING THE OXSOCKET8X1); 6. INSTALL THE PORT (PRESS FIT) IN THE OPENING AT THE BACK (BEHIND THE TWEETER). YOU CAN APPLY ELECTRICAL TAPE AROUND THE PORT TO HAVE A TIGHTER FIT AND SEAL IT PROPERLY: Description: Projection Method: THIRD ANGLE **SOLEN PURE - ASSEMBLY INSTRUCTIONS (2/2)** All Dimensions: Drawing Scale: 1:2 mm [in] This drawing and any information Material: N/A or descriptive material set out on it are the confidential and Drawn by: copyright property of Solen **LAURENT TARDIF** Électronique INC, and MUST SOLEN ÉLECTRONIQUE NOT BE DISCLOSED, COPIED, Sheet Size: Drawn Date: LOANED in whole or part or 3940 BI VD SIR-WII FRIDused for any purpose without the 2024-07-10 LETTER LAURIER, written permission of Solen (450) 656-2759 Sheet: **7 of 17** Revision: #1 Électronique INC. solen@solen.ca 2 5



















